

WINDOW WELL SCENES®

installation guide

*****Important***** Leave Velcro® indoors (in a warm area) for 24 hours or warm it up with a hair dryer for about 30 seconds prior to installation to activate adhesive.

*****NOTE***** Window well covers are not necessary for our product, but we do recommend them for more years of enjoyment.

STEP 1: PREPARE

Clean out debris in the window well and remove a few inches of rock or other material from the bottom of the window well; this will enable you to roll the panel into place with greater ease when installing it and will put the lower edge below the rocks when they are replaced which will anchor it. Measure your window well in several places from the top to the bottom (height) and from side to side (width). **Caution: Be generous with your measurements; the curved dimension may be difficult to measure perfectly. You can always trim more off, but you can't add any back!** Clean the metal or concrete with rubbing alcohol or other appropriate solvent to remove any residue where the adhesive strips will be placed. If your window well is especially deep, plan it so that about one inch of rock covers the bottom edge. Don't be concerned if the panel doesn't reach the top rim of the well; the top cannot be seen from the room.



STEP 2: CROP

Lay out your Window Well Scenes® image-side up on a flat surface. Anchor the corners with something heavy if needed. Do not attempt to roll the panel the other way to flatten it; like other plastic materials, styrene can crack and break if folded back on itself. Mark your window well measurements to select the area that looks best for your window well.



STEP 3: TRIM

Using a straight edge and a sharp blade/utility knife or using appropriate scissors, carefully cut along the lines you made in step 2. Protect the surface underneath the panel with a piece of wood or cardboard to avoid damage from the blade. Place the panel into the window well along the curve to make any final size adjustments.

STEP 4: ATTACH

Attach the individual Velcro® brand fasteners to the window well on the ridges that bump out toward the room. Avoid placing pieces on rusted areas, or remove the rust. Put three pieces down each side being sure to hit the spots where the corners will be, and put three down the middle. Put additional pieces along the top edge as needed. Leave the male and female sides connected as well as the backing paper and attach the strips to the metal. Starting on the free side of the rolled panel, remove the remaining backing paper from a set of fasteners and gradually unroll the panel so that the top is level with the top edge of the metal.



STEP 5: FINISH

Replace the rock or other material in the bottom of the well to cover the bottom edge of the panel and add any additional decoration desired such as larger rocks, driftwood, or plants. Stand back and admire the dramatic change in your view. Enjoy!



Important note: Do not remove or cover up an egress/escape ladder to install this product.

Importante nota: no remover o cubrir arriba de la escalera de metal para instalar este producto.

©Sinergi Enterprises, Inc. 2007.

PRODUCT LIMITED WARRANTY

The product is warranted by Sinergi Enterprises, Inc. for one year from date of retail purchase to be free of manufacturer's defects in material and/or workmanship, including fading of the original image. Components and materials not manufactured by Sinergi Enterprises, Inc. are warranted only to the extent of the original manufacturer's warranty. The sole obligation of Sinergi Enterprises, Inc. under this limited warranty is to replace or repair FOB Denver, at the option of Sinergi Enterprises, Inc., any part which, in the sole opinion of Sinergi Enterprises, Inc., is defective. Under no circumstances will Sinergi Enterprises, Inc. be responsible for mis-installation of the product.

This warranty is made in lieu of all other warranties, expressed or implied, including, but not limited to, any implied warranty of merchantability and/or fitness for a particular purpose or use. There are no warranties express or implied beyond the description of the product on the original product packaging. Sinergi Enterprises, Inc. expressly disclaims liability for incidental, special, or consequential damages of any nature. Sinergi Enterprises, Inc. specifically disclaims any liability arising from owner's failure to maintain the product. Replacement of parts or modification of the original product will void this warranty.

Sinergi Enterprises, Inc. neither assumes nor authorizes any person or entity to assume for it any obligations or liabilities not expressly stated herein.

